



IBATTERYTRAY001 BATTERY TRAY INSTRUCTION MANUAL

IBATTERYTRAY001 FORD PX / PX MKII RANGER DESIGNED TO GO WITH FULL RIVER DC40-12 BATTERY

1. Raise rear seat squab and remove plastic liner from drivers side compartment.

2. Place supplied coach bolts through base plate.



3. Place battery tray into position. Drill 2 x 6mm holes in top lip, use M6 bolts to secure. Using supplied self-drilling screws secure lower section.

Self drilling screws



4. Secure battery in place using supplied clamp. Cover battery terminals with suitable insulation and ensure seat clearance.

