



### To Suit Toyota Prado 150 and FJ Cruiser

**NOTE:** This sway bar offset mounting kit has been designed to re-locate and move the sway bar forward to increase clearance with the front struts.

#### Kit Contains:

- 2 x offset mounting brackets
- 4 x M10 cap head bolts
- 4 x M10 spring washers

#### Tools & Equipment

- 1 x 16mm socket and extension
- 1 x ratchet
- 1 x 8mm allen key / socket



**NOTE:** It may be necessary to remove underbody protection plates.

1. Unbolt and remove both left and right original sway bar mounting brackets.
2. Install new offset sway bar mounts using original rubber bushes.
3. Ensure the new offset mounts have been installed with directional arrow facing towards the front of the vehicle.
4. Secure using new mounting hardware (4 x M10 bolts and spring washers), and tighten to 45Nm.
5. Check operational clearance around all parts.



**Warranty will be voided by damage or failure caused by incorrect procedure.**

**Before proceeding to install Billet Aluminium Sway Bar Mounts, please fully read instructions and ensure that necessary tools are on hand.**

**Always wear personal safety protection ie. Safety glasses and gloves to prevent injury.**