



INSTALLATION GUIDE

**IMPORTANT: MUST BE USED IN CONJUNCTION
WITH AN IRONMAN 4X4 BULL BAR**

IRP050

MITSUBISHI MQ TRITON 2015+




- Ironman 4x4 Recovery Points fit to the chassis
- It will take about 45 mins to install, or 10 mins if installed with fitment of bull bar
- Below is a list of required tools for installing your Ironman 4x4 Recovery Points:
 - **13, 17, and 19mm socket**
 - **19mm spanner**

IMPORTANT: Recovery Point installations should only be done by a qualified person and it is the responsibility of this person to ensure correct fitment.

1. Before installation check recovery points are compatible with your vehicle.


2. Remove all fasteners from the chassis strengthening bracket.



3. Align recovery point to chassis.



4. Re-use the U-bolt from the strengthening bracket and leave loose.



5. Re-use the long bolt, washers and nut removed from bracket, then pass back through the chassis.



6. Place the spacer plate on the other side of the factory tie down point and use the supplied 10.9 tensile bolt, 2 flat washers, spring washer and nut.



7. Use the supplied 10.9 bolts in the remaining holes.



8. Tighten all bolts.